

TEGO® Care SE 121

Natural emulsifier and co-emulsifier for O/W emulsions

Intended use

O/W emulsifier for skin care

Benefits at a glance

- PEG-free, fully based on natural renewable raw materials
- Recommended usage concentration of 2 – 5%
- Co-emulsifier for O/W creams and lotions

INCI (PCPC name)

Sucrose Stearate

Chemical and physical properties (not part of specifications)

Form	pellets/pellet conglomerates*
HLB value	approx. 13

*Note: conglomerates can occur due to filling temperature and packaging pressure.

Main properties

- TEGO® Care SE 121 is produced from natural renewable raw materials.
- TEGO® Care SE 121 is a mild, PEG-free co-emulsifier for O/W creams and lotions.
- Due to its chemical composition as a sucrose ester TEGO® Care SE 121 has moisturizing properties.
- TEGO® Care SE 121 does not contain any solvent or preservative.

Preparation

It is suggested to add TEGO® Care SE 121 to the water phase. It is also possible to add TEGO® Care SE 121 to the oil phase.

Further manufacturing conditions correspond to the principles of common processing for O/W emulsions.

Application

TEGO® Care SE 121 is especially suitable for O/W creams and lotions for

- Facial and body care
- After sun care
- Baby care

Recommended usage concentration

2.0 – 5.0% TEGO® Care SE 121

Packaging

450 kg pallet (18 x 25 kg bag)

Hazardous goods classification

Information concerning

- classification and labelling according to regulations for transport and for dangerous substances
- protective measures for storage and handling
- measures in case of accidents and fires
- toxicity and ecological effects

is given in our material safety data sheets.

Guideline formulations

O/W Moisturizing Body Lotion SZ 37/14-3	
Phase A	
TEGIN® 4100 Pellets (Glyceryl Stearate)	0.50%
Stearic Acid	0.50%
TEGOSOFT® MM (Myristyl Myristate)	1.00%
TEGOSOFT® APM (PPG-3 Myristyl Ether)	3.00%
TEGOSOFT® OP (Ethylhexyl Palmitate)	4.20%
Cyclopentasiloxane	5.00%
Tocopheryl Acetate	0.50%
ABIL® 350 (Dimethicone)	0.30%
Phase B	
TEGO® Care CG 90 (Cetearyl Glucoside)	1.00%
TEGO® Care SE 121	2.00%
Allantoin	0.20%
Panthenol	0.50%
Glycerin	3.00%
Water	76.70%
Phase C	
TEGO® Carbomer 141 (Carbomer)	0.20%
TEGOSOFT® OP (Ethylhexyl Palmitate)	0.80%
Phase D	
Sodium Hydroxide (10% in water)	0.60%
Phase Z	
Preservative*, Perfume	q.s.
Preparation:	
<ol style="list-style-type: none"> Heat phase A and B separately to approx. 80 °C. Add phase A to phase B with stirring.¹⁾ Homogenize. Cool with gentle stirring to approx. 60 °C and add phase C. Homogenize for a short time. Cool with gentle stirring and add phase D below 40 °C. 	
¹⁾ Important: If phase A has to be charged into the vessel first, phase B must be added without stirring .	
*Formulation was tested with 1.0% Phenoxyethanol; Ethylhexylglycerin (Euxyl PE 9010, Schülke & Mayr GmbH)	

Facial Mask SZ 37/14-5		
Phase A		
ABIL® Care 85 (Bis-PEG/PPG-16/16 PEG/PPG-16/16 Dimethicone; Caprylic/Capric Triglyceride)		1.50%
TEGINACID® C (Cetareth-25)		1.00%
TEGIN® M Pellets (Glyceryl Stearate)		3.50%
Stearyl Alcohol		2.00%
Stearic Acid		1.00%
TEGOSOFT® MM (Myristyl Myristate)		1.50%
TEGOSOFT® DC (Decyl Cocoate)		6.00%
TEGOSOFT® TN (C12-15 Alkyl Benzoate)		8.50%
Prunus Amygdaluy Dulcis (Sweet Almond) Oil		5.00%
Phase B		
TEGO® Care SE 121		2.00%
Glycerin		3.00%
Panthenol		0.50%
Allantoin		0.20%
Water		63.50%
Phase C		
TEGO® Carbomer 134 (Carbomer)		0.10%
Mineral Oil (30 mPas)		0.40%
Phase D		
Sodium Hydroxide (10% in water)		0.30%
Phase Z		
Preservative*, Perfume		q.s.
Preparation:		
<ol style="list-style-type: none"> Heat phase A and B separately to approx. 80 °C. Add phase A to phase B with stirring.¹⁾ Homogenize. Cool with gentle stirring to approx. 60 °C and add phase C. Homogenize for a short time. Cool with gentle stirring and add phase D below 40 °C. 		
¹⁾ Important: If phase A has to be charged into the vessel first, phase B must be added without stirring .		
*Formulation was tested with 0.8% Phenoxyethanol; Ethylhexylglycerin (Euxyl PE 9010, Schülke & Mayr GmbH)		

O/W Body Souffle Cream SZ 37/14-1	
Phase A	
AXOL® C 62 Pellets (Glyceryl Stearate Citrate)	1.50%
TEGIN® M Pellets (Glyceryl Stearate)	2.00%
TEGO® Alkanol 1618 (Cetearyl Alcohol)	3.00%
TEGOSOFT® DEC (Diethylhexyl Carbonate)	20.00%
Phase B	
TEGO® Care SE 121	1.00%
Glycerin	3.00%
Water	67.10%
Phase C	
TEGO® Carbomer 341 ER (Acrylates / C10-30 Alkyl Acrylates Crosspolymer)	0.20%
TEGOSOFT® DEC (Diethylhexyl Carbonate)	0.80%
Phase D	
Sodium Hydroxide (10% in water)	0.60%
Phase E	
TEGO® Betain 810 (Capryl/Capramidopropyl Betaine)	0.80%
Phase Z	
Preservative*, Perfume	q.s.
Preparation:	
<ol style="list-style-type: none"> Heat phase A and B separately to 80 °C. Add phase A to phase B with stirring.¹⁾ Homogenize. Cool with gentle stirring to approx. 60 °C and add phase C. Homogenize for a short time. Cool with gentle stirring and add phase D and E below 40 °C. 	
¹⁾ Important: If phase A has to be charged into the vessel first, phase B must be added without stirring .	
*Formulation was tested with 1.0% Phenoxyethanol; Ethylhexylglycerin (Euxyl PE 9010, Schülke & Mayr GmbH)	

Body Lotion SZ 29/14-A4	
Phase A	
TEGIN® 4100 Pellets (Glyceryl Stearate)	0.50%
Stearic Acid	0.50%
TEGOSOFT® APM (PPG-3 Myristyl Ether)	1.30%
TEGOSOFT® OP (Ethylhexyl Palmitate)	1.60%
TEGOSOFT® DEC (Diethylhexyl Carbonate)	1.60%
Phase B	
TEGO® Care SE 121	2.00%
Glycerin	3.00%
Water	87.90%
Phase C	
TEGO® Carbomer 141 (Carbomer)	0.20%
TEGOSOFT® OP (Ethylhexyl Palmitate)	0.80%
Phase D	
Sodium Hydroxide (10% in water)	0.60%
Phase Z	
Preservative*, Perfume	q.s.
Preparation:	
<ol style="list-style-type: none"> Heat Phase A and B separately to 80 °C. Add phase A to phase B with stirring.¹⁾ Homogenize. Cool with gentle stirring to approx. 60 °C and add phase C. Homogenize for a short time. Cool with gentle stirring and add phase D below 40 °C. 	
¹⁾ Important: If phase A has to be charged into the vessel first, phase B must be added without stirring .	
*Formulation was tested with 0.8% Dipropylene Glycol; Methylparaben; Ethylparaben; Aqua; Methylisothiazolinone (Microcare MEM, Thor GmbH)	

O/W Cream SZ 29/14-B5	
Phase A	
TEGIN® M Pellets (Glyceryl Stearate)	5.50%
Stearyl Alcohol	2.00%
TEGOSOFT® APS (PPG-11 Stearyl Ether)	3.20%
TEGOSOFT® liquid (Cetearyl Ethylhexanoate)	3.20%
TEGOSOFT® OP (Ethylhexyl Palmitate)	7.60%
Phase B	
TEGO® Care SE 121	5.50%
Glycerin	2.00%
Water	71.00%
Phase Z	
Preservative*, Perfume	q.s.
Preparation:	
<ol style="list-style-type: none"> 1. Heat Phase A and B separately to 75 °C. 2. Add phase A to phase B with stirring.¹⁾ 3. Homogenize. 	
¹⁾ Important: If phase A has to be charged into the vessel first, phase B must be added without stirring .	
*Formulation was tested with 0.8% Dipropylene Glycol; Methylparaben; Ethylparaben; Aqua; Methylisothiazolinone (Microcare MEM, Thor GmbH)	

O/W Body Butter SZ 29/14-C2	
Phase A	
TEGO® Alkanol 1618 (Cetearyl Alcohol)	3.00%
TEGIN® M Pellets (Glyceryl Stearate)	5.00%
TEGOSOFT® MM (Myristyl Myristate)	1.00%
TEGOSOFT® CR (Cetyl Ricinoleate)	1.00%
TEGOSOFT® DC (Decyl Cocoate)	7.00%
TEGOSOFT® OER (Oleyl Erucate)	5.00%
Glycine Soja (Soybean) Oil	3.00%
Butyrospermum Parkii (Shea) Butter	7.00%
Theobroma Cacao (Cocoa) Seed Butter	5.00%
Phase B	
TEGO® Care SE 121	3.50%
Glycerin	5.00%
Water	54.50%
Phase Z	
Preservative*, Perfume	q.s.
Preparation:	
<ol style="list-style-type: none"> 1. Heat Phase A and B separately to 75 °C. 2. Add phase A to phase B with stirring.¹⁾ 3. Homogenize. 	
¹⁾ Important: If phase A has to be charged into the vessel first, phase B must be added without stirring .	
*Formulation was tested with 1.0% Phenoxyethanol; Ethylhexylglycerin (Euxyl PE 9010, Schülke & Mayr GmbH)	

Natural O/W Lotion SZ 29/14-E1	
Phase A	
TEGOSOFT® OER (Oleyl Erucate)	3.00%
TEGOSOFT® MM (Myristyl Myristate)	2.00%
TEGOSOFT® DC (Decyl Cocoate)	2.00%
Simmondsia chinensis (Jojoba) Seed Oil	5.00%
TEGO® Alkanol 1618 (Cetearyl Alcohol)	1.00%
Phase B	
TEGO® Care SE 121	3.00%
Water	74.50%
Phase C	
Glycerin	3.00%
Xanthan Gum	0.50%
Water	5.00%
Phase D	
Sodium Hydroxide (10% in water)	0.20%
Phase E	
Benzyl Alcohol, Glycerin, Benzoic Acid, Sorbic Acid (Rokonsal BSB-N, Ashland)	0.80%
Phase Z	
Perfume	q.s.
Preparation:	
<ol style="list-style-type: none"> 1. Heat Phase A and B separately to 80 °C. 2. Add phase A to phase B with stirring.¹⁾ 3. Homogenize. 4. Add phase D below 30 °C. 5. Add phase E and adjust pH of formulation to 5.0 – 5.5. 	
¹⁾ Important: If phase A has to be charged into the vessel first, phase B must be added without stirring .	

B 08/16

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments.

The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used. (Status: April, 2008)

Evonik Industries AG

Goldschmidtstraße 100 45127 Essen, Germany

P.O.BOX 45116 Essen PHONE + 49 201 173-2909 FAX +49 173-712909

personal-care@evonik.com www.evonik.com/personal-care